VOICE COMMAND

INSTRUCTIONS

OPEN THE BATTERY COMPARTMENT

to find the manual controls for your atmosphere light settings

PRESS AND HOLD THIS BUTTON

for more than 2 seconds each time to switch the atmosphere lamp mode cyclically:

MONOCHROMATIC MODE

BREATHING MODE

BURST MODE

MUSIC RHYTHM MODE

COLORFUL MODE

MARQUEE MODE

OVERLAY MODE

CUSTOM MODE

TOUCH THIS BUTTON

to change the brightness of the atmosphere lamp or turn off the atmosphere lamp.

VENOM EV

VOICE CONTROL SETPS

To wake up your voice controls just say; **"HELLO ATMOSPHERE LIGHT!"** Then say the function you want to control. When you are ready to end the voice operation, just say; **"OVER"** or the voice operation cancels automatically after 5 seconds of no commands.

VOICE CONTROL COMMAND PHRASES

1	Turn on the atmosphere lamp	18	Green | Turn to green
2	Turn off the atmosphere lamp	19	Blue | Turn to blue
3	Turn up the brightness | Turn up	20	Cyan | Turn to cyan
4	Turn down the brightness | Turn down	21	Purple | Turn to purple
5	Brightest | Maximum brightness	22	Pink | Turn to pink
6	Darkets | Minimum brightness	23	White | Turn to white
7	Brightness to one	24	Yellow | Turn to yellow
8	Brightness to two	25	Orange | Turn to orange
9	Brightness to three	26	Next | Change
10	Brightness to four	27	Previous *(Switch to previous color)*
11	Brightness to five	28	Hurry up *(Speed up the dynamic display effect of lights)*
12	Burst Mode	29	Slow down *(Slow down the dynamic display effect of lights)*
13	Colorful mode	30	Turn to monochrome
14	Marquee mode	31	Turn to music rhythm
15	Overlay mode	32	Breathing mode
16	Custom mode		
17	Red | Turn to red		